

FEATURES:

- can be sanded and accepts any type of finish
- made from select veneer stock without adhesive backing
- can be applied with contact cement without clamping or with white glue using clamps
- a very economical way to cover edges of particle board, veneer core plywoods, etc.
- excellent for banding edges
- widths listed are nominal generally + / - 1/16"
- edging dimensions available only in listed sizes

APPLICATION:

Plyedge is the easy and economical way to finish plywood edges.

SPECIFICATIONS:

•veneer thickness is approximately 1/28" with exception

	<u>1" x 6'</u>	<u>1-1/2" x 8'</u>	<u>2" x 8'</u>
Birch	19372.....	19380.....	19398
Oak	19406.....	19414.....	19422
Walnut	19430.....	19448.....	19455
Mahogany	19463.....	19471.....	19489
Cherry	19497.....	19505.....	19513

of walnut that is 1/36"

- veneer width will be + or - 1/16" of listed width
- oak edging is mixed red or white, cannot be specified

INSTALLATION:

Method I : Contact cement

1. Apply contact cement to core edge and one side of edging, according to manufacturers instructions
2. Apply edging, roll and then trim and sand off surplus

Method II : White or Cream Liquid Glue

1. Apply and spread glue to core edge and side of edging.
2. Position edging on core edge, place 1" back-up strip to edging and clamp.