

FEATURES:

- 4" radius
- made from white oak
- pre-drilled and countersunk screw holes
- adds strength to chair back
- sold in pairs

APPLICATION:

Used for replacing broken braces and for strengthening round back posts.

SPECIFICATIONS:

INSTALLATION:

A. Retrofit

1. Remove old/broken chair braces.
2. Place a new brace in position on back/seat and check to see if old screw holes align. If holes are aligned, attach braces to chair with #9 flat head or oval head screws.
3. If new braces do not align with old holes in seat frame and back posts, drill new pilot holes and then attach braces as described in step #2.

