


Exploded View

Some contractor's saws lose accuracy when their blades (and their cantilevered motors) are cranked to 45°. This jig solves that problem and adds a considerable degree of safety to the mix as well.

Table
(Top and End Views)



MATERIAL LIST

	T x W x L
1 Table (2)	1/2" x 13 5/8" x 18"
2 Base (1)	1/2" x 12" x 18"
3 Supports (2)	3/4" x 7" x 7"
4 Adjustable Miter Bar (1)	3/8" x 3/4" x 18"
5 Hex Head Bolts (2)	3/4" x 5/16"-18
6 T-Track Intersection Kits (4)	1/2" x 3/4" x 3"
7 Aluminum T-Tracks (6)	1/2" x 3/4" x 3"
8 Hold-Down Clamps for T-Track (2)	Aluminum
9 Fence (1)	1/2" x 3/4" x 14"
10 T-Knobs (2)	2" x 5/16"-18
11 T-Slot Bolts (2)	2 1/2" x 5/16"-18
12 Washers (4)	5/16" Dia.
13 Screws (12)	#6 x 5/8"